



## SILHOUETTE LEVERS

## 1049

**FITS: '96-UP H-D MODELS WITH CABLE CLUTCH (EX. '04-UP XL)**

### PARTS INCLUDED

- 1 Silhouette Levers (pr)
- 1 New Style Bushing
- 1 Old Style Bushing
- 1 8-32 x 3/8" Slotted Machine Screw — Zinc
- 1 Anti-Rattle Clip
- 1 Instruction Sheet

*Please read and understand entire instructions before starting installation.*

### THANK YOU FOR CHOOSING KÜRYAKYN!

### TOOLS SUGGESTED

Small external snap ring pliers, 1/2" and 9/16" Open end wrenches, Grease

### PROCEDURE

**STEP 1** With your snap ring pliers, remove the snap rings located on the bottom of each lever pivot pin. Be careful not to lose the snap rings. Remove both pivot pins.

### STEP 2 BRAKE SIDE

Carefully remove the brake lever from the master cylinder assembly. Place a small amount of grease on the pivot pin. Check to be sure the nylon bushing is in place in the lever and replace the lever into the master cylinder — **DO NOT FORCE IT!** If it does not go in with ease, make sure the thin tab on the brake lever is positioned at the end of the master cylinder plunger. When the pivot pin can be inserted easily through the master cylinder housing and the lever, it is positioned correctly. Gently squeeze the brake control a few times to insure proper operation. Replace the snap ring on the pivot pin.

**IMPORTANT** As a safety precaution, we recommend testing to be certain the front brake is not dragging. To do this you may need the help of a friend. With a small jack or lift, elevate the front wheel off the ground. Spin the front wheel; it should spin freely for a couple of revolutions. If it moves with noticeable resistance or seems to stick or bind, the brakes are dragging and one should go back and review the installation to determine the cause of this brake drag before the motorcycle is operated.

-cont.-

### CUSTOMER SERVICE

877.370.3604 (toll free)

### INSTALLATION QUESTIONS

techsupport@kuryakyn.com  
or call 715.247.2983

### LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

### ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA All Rights reserved.



## STEP 3 CLUTCH SIDE

Loosen the clutch cable adjuster (PIC.1) so the maximum amount of slack is attained. (Refer to the picture sequence.) Pull the cable housing as far out of the clutch perch as possible (PIC.2) and rotate the cable and housing away from the handlebar (PIC.3). The lever may now be pulled free of the perch (PIC.4). Slide the nylon cable anchor out of the stock lever freeing the cable. (Now is a good time to lube your clutch cable!) Apply a small amount of grease to the pivot pin. Make sure the nylon bushing is in place in the new lever, and reassemble in reverse order of disassembly. Replace the snap ring on the pivot pin. Adjust the clutch cable so there is about 1/8" of free play in the lever. Tighten the adjuster locknut (easy, or you can break the adjuster!) Replace the rubber boot or cover over the adjuster.

PIC.1



PIC.2



PIC.3



PIC.4



*Ride On!*